Name: - Naitrik Solanki

# **Assignments:**

# Module – 2 : Installation and Maintenance of Hardware and Its

## **Section 1: Multiple Choice**

- 1. Which of the following precautions should be taken before working on computer hardware?
- a) Ensure the computer is plugged in to prevent electrostatic discharge.
- b) Wear an anti-static wrist strap to prevent damage from electrostatic discharge.
- c) Work on carpeted surfaces to prevent slipping.
- d) Use magnetic tools to handle components more easily.
- Ans. B) Wear an anti-static wrist strap to prevent damage from electrostatic discharge.
- <u>Note</u>:- Electrostatic discharge (ESD) can cause serious damage to sensitive computer components such as the CPU, RAM, and Motherboard.
- 2. What is the purpose of thermal paste during CPU installation?

- a) To insulate the CPU from heat.
- b) To provide mechanical support for the CPU.
- c) To improve thermal conductivity between the CPU and the heat sink.
- d) To prevent the CPU from overheating.

Ans :- C) To improve thermal conductivity between the CPU and the heat sink.

<u>Note</u>:- Thermal paste fills these gaps and allows heats to transfer more efficiently from the CPU to the heat sink, helping to maintain optimal temperatures.

- 3. Which tool is used to measure the output voltage of a power supply unit (PSU)?
- a) Multimeter
- b) Screwdriver
- c) Pliers
- d) Hex key

Ans :- A) Multimeter

<u>Note</u>:- A multimeter is a electronic measuring tool that can measure voltage, current, and resistance. To check the output voltage of a power supply unit (PSU), you use the DC voltage.

- 4. Which component is responsible for storing BIOS settings, such as date and time, even when the computer is powered off?
- a) CMOS battery
- b) CPU
- c) RAM
- d) Hard drive

Ans :- A) CMOS battery

<u>Note</u>:- The COMS battery (Complementary Metal-Oxide Semiconductor battery) provides power to a small memory chip on the motherboard that stores BIOS settings, such as the system clock (date and time), boot order, and other hardware configuration.

## **Section 2: True or False**

5. True or False: When installing a new hard drive, it is essential to format it before use.

Ans. True

<u>Note</u>:- When you install a new hard drive, it must be formatted before it can be used to store data. Formatting sets up a file system (like NTFS, exFAT, or FAT32).

6. True or False: A POST (Power-On Self-Test) error indicates a problem with the CPU.

Ans. False

Note: A POST (Power-On Self-Test) error does not necessarily indicate a problem with the CPU POST is a diagnostic testing sequence run by the BIOS or UEFI firmware.

7. True or False: It is safe to remove a USB flash drive from a computer without ejecting.

Ans. :- False

<u>Note</u>:- When a USB flash drive is connected to a computer to reading or writing. If remove the USB drive without ejecting the data transfers could be interrupted, data corruption or loss data and file and will be error.

## **Section 3: Short Answer**

8. Describe the steps involved in installing a new graphics card in a desktop computer.

Ans. Steps to install new graphics card :-

**1. Open the computer case :-** Remove the screws that hold the side panel of the computer case and gently pry it open.

- **2. Locate the PCIe slot :-** Identify an available PCIe (Peripheral Component Interconnect Express) slot on the motherboard.
- **3.** Remove any existing graphics card: If there's an existing graphics card, carefully remove it from the PCIe slot.
- **4. Prepare the new graphics card :-** Remove the new graphics card from its packaging and handle it by the edges to prevent static damage.
- **5. Align the graphics card :-** Align the gold contact on the graphics card with the PCIe slot.
- **6. Install the graphics card :-** Gently push the graphics card into the PCIe slot until it clicks into place.
- **7. Secure the graphics card :-** Use screws to secure the graphics card to the case.
- **8. Connect power cables :-** Connect the power cables from the power supply unit (PSU) to the graphics card.
- **9. Connect any additional cables :-** Connect any additional cables, such as HDMI or Display Port cables, to the graphics card.
- **10. Close the computer case :-** Put the side panel back on the computer case and screw it in place.
- **11. Plug in the power cord :-** Plug in the power cord and any other cables.
- **12. Turn on the computer :-** Turn on the computer and install the graphics card drivers.

9. What is RAID, and what are some common RAID configurations?

Ans. RAID (Redundant Array of Independent Disks) is a data storage technology that combines multiple physical disks into a single logical unit to improve performance, redundancy, or both.

#### RAID Configurations :-

- **1. RAID 0 (Striping) :-** Splits data across multiple disks, improving performance but offering no redundancy.
- **2. RAID 1 (Mirroring) :-** Duplicates data on two or more disks, providing redundancy and fault tolerance.
- **3. RAID 5 (Striping with Parity) :-** Combines striping and parity information, offering a balance between performance and redundancy.
- **4. RAID 6 (Striping with Double Parity) :-** Similar to RAID 5, but with an additional parity block, providing extra redundancy.
- **5. RAID 10 (Mirroring and Striping) :-** Combines RAID 1 and RAID 0, offering both redundancy and improved performance.

#### **Section 4: Practical Application**

10. Demonstrate how to replace a CPU fan in a desktop computer.

- Ans. 1. Shut down the computer :- First power off a computer.
- **2. Unplug the power cord :-** Unplug the power cord and any other cables from the back computer.
- **3. Open the computer case :-** Remove the screws that hold the side panel of the computer case and it open.
- **4. Locate the CPU fan :-** Identify the CPU fan, usually located on top of the CPU heatsink.
- **5. Disconnect the fan power cable :-** Carefully disconnect the fan power cable from the motherboard or CPU fan header.
- **6. Remove any screws or clips :-** Remove any screws or clips that hold the CPU fan in place.
- **7. Gently lift the CPU fan :-** Carefully lift the CPU fan off the CPU heatsink.
- **8. Clean the CPU heatsink :-** Clean the CPU heatsink of any dust or debris.
- **9. Apply new thermal paste :-** The buy a new CPU fan and apply a small amount of thermal paste to the CPU on top surface.
- **10. Install the new CPU fan :-** The new CPU fan on the CPU heatsink, ensuring proper alignment.
- **11. Secure the CPU fan :-** Use screws or clips to secure the CPU fan in place.

- **12. Reconnect the fan power cable :-** Connect the fan power cable to the motherboard or CPU fan header.
- **13. Close the computer case :-** Put the side panel back on the computer case and screw it in place.
- **14. Plug in the power cord :-** Plug in the power cord and any other cables.
- **15. Turn on the computer :-** Turn on the computer and monitor the CPU fan to ensure it's working properly.

## **Section 5: Essay**

11. Discuss the importance of regular maintenance for computer hardware and provide examples of maintenance tasks.

#### Ans.

- Regular maintenance of computer hardware :-
  - **1. Prevent Overheating :-** Dust buildup and malfunctioning fans can cause overheating, leading to component failure.
  - **2. Ensure optimal performance :-** Regular maintenance helps maintain system performance, preventing slowdowns and crashes.
  - **3. Extend hardware lifespan :-** Proper care and maintenance can extend the lifespan of hardware components.

- **4. Prevent data loss :-** Regular backups and disk checks can prevent data loss due to hardware failure.
- Examples of Maintenance Tasks :-
  - **1. Dust cleaning :-** Regularly clean dust from fans, heatsink, and other components.
  - **2. Fan maintenance :-** Check and replace fans as needed to ensure proper airflow.
  - **3. Disk check :-** Run disk checks to identify and fix errors, preventing data loss.
  - **4. Backup data :-** Regularly back up important data to prevent loss in case of hardware failure.
  - **5. Update drivers :-** Keep drivers up-to-date to ensure optimal performance and compatibility.
  - **6. Monitor temperature :-** Monitor system temperature to prevent overheating.
  - **7. Inspect cables :-** Regularly inspect cables for damage or wear, replacing them as needed.
  - **8. Run disk cleanup :-** Run disk cleanup tools to remove temporary files and free up disk space.